

Wax Release Agent IFU

1. Gently squeeze the Wax Release Agent bottle to place a pea sized dollop of wax upon the designated build table. (Figure 1)



Figure 1: Proper amount of wax on build table

2. Wipe Wax Release Agent with lint free paper towel uniformly across the build table until the surface is covered with a barely visible, thin, shiny layer of wax. (Figure 2 and Figure 3)



Figure 2: Wax application to build table



Figure 3: Build table with wax applied before buffing

3. Let the wax rest for 2 minutes then buff the table with a lint free paper towel. (Figure 4)




Figure 4: Build table with wax applied after buffing

4. The build table is now ready to print the resin.